

Ultramax Glass Adhesive Mount Antenna Installation Guide

Note: The mounting tape is provided separately. One side of the antenna has text indicating it should face the sky. If mounting on the inside of a windshield, the tape goes on the text side of the antenna, but when mounting it on a flat surface (such as a dashboard), the tape goes on the other.

1. Where the antenna will mount to the vehicle, clean the surface with the provided alcohol wipe to remove dust, dirt, and oil.
2. Remove one side of backing liner from the mounting tape, and then place the mounting tape on the proper side of the antenna as indicated above.
3. Remove the backing liner on the other side of the mounting tape, and then position the antenna and adhere it to the vehicle using firm hand pressure.

Important Highlights and Key Points for Proper Antenna Installation

- *The antenna must be mounted horizontally - parallel to the ground (not mounted on a vertical surface).
- *The antenna must be mounted to a flat, clean dry surface. Avoid mounting the antenna near panel seams and or rivets so the antenna gaskets can seal properly.
- *When routing cables, DO NOT PULL ON CONNECTORS! Pulling directly on connectors will cause internal damage and loss of the signal at the radio receiver, GPS or modem. When routing cables, pull on the coaxial cable only!
- *IMPORTANT! Be sure that the surface temperature of the vehicle where the antenna will be mounted is at least 60°F before installation. Cooler surface temperatures will prevent full adhesion of the antenna.